

www.alcosales.com

- 6851 High Grove Blvd., Burr Ridge, IL 60527 •
- info@alcosales.com

- Phone: 630-655-1900 Toll Free: 800-323-428
- Toll Free: 800-323-4282 Fax: 630-655-1990

Toll Free: 800-323-4282

Reconditioning Process

Stretchers

- 1. All stretchers are visually inspected for bent or broken parts. Any bent or broken parts are repaired or replaced so that operating features function properly.
- 2. The stretchers are completely disassembled.
- 3. The stretchers are cleaned inside and outside of the frame and all stickers or decals are removed.
- 4. The stretcher frames are sanded completely in a separate room.
- 5. Lower base is inspected and cleaned and hoods replaced if needed.
- 6. Stretcher frames are painted in a professional paint booth. All parts and frames dry for 24 hours before they are touched again.
- 7. Stretchers are then reassembled to include the following:
 - a. Pump pistons are replaced
 - b. Locking casters or brake bars are replaced
 - c. Cylinders are inspected and replaced if needed
 - d. Oil levels are checked
 - e. New pads
- 8. A final inspection of the stretchers operating features are rechecked and tested to ensure the stretcher is performing to manufacturer's standards.
- 9. Stretchers are shipped and wrapped in protective plastic; Blanket wrapped and positioned on wheels only.

^{**}Warranty information: One year on parts and tech assistance by phone**