
Formatrac[®] Bendable Track

AL-76800 Installation Instructions





1. Determine the length of track needed. Open corner of the box and pull out the number of feet needed as illustrated in FIG.1a. Small dots are printed every 12" on the side of the track as shown in FIG.1b.Use this as an aid when measuring. Cut the track with a hack saw.


2. **IMPORTANT**: To help straighten rolled track, gently reverse roll the section of track to be installed. When reverse rolling do not roll too tightly; keep roll diameter at approximately 4 to 5 feet[1220mm to 1524mm]. See FIG. 2

3. Determine the layout of track on the ceiling to decide the location of ceiling clip assemblies and the amount of track needed.

Ceiling with ceiling grid.

4. Attach ceiling clip assembly to the ceiling grid every 18"-24" [458mm to 610mm] on average. Additional clips may be required 6" [153mm]before and 6" [153mm] after a bend. Slide the ceiling clip over the ceiling grid. Push the clip tight to the ceiling grid and secure it by tightening the screw. See FIG. 3a & 3b.

FIG. 3b





alcosales.com • 800.323.4282 • 800.950.1167 6851 High Grove Blvd, Burr Ridge, IL 60527 USA

Formatrac[®] Bendable Track


AL-76800

Installation Instructions


Ceiling without ceiling grid.


**If attaching spring clip to the ceiling grid without the gridclip, use a #8 x 3/4" pan head sheet metal screw and fasten the spring clip to the grid. (Installer supplied)

For other ceiling types, attach spring clips to the ceiling with fasteners appropriate for that substrate.




WOOD BLOCKING





5. Start at one end of the installation and snap the track into the spring clip. Continue to the next clip and snap the track into place until the entire track is installed. See FIG. 4.

If needed, add ceiling clip assemblies where the track bends.



alcosales.com • 800.323.4282 • 800.950.1167 6851 High Grove Blvd, Burr Ridge, IL 60527 USA



Formatrac[®] Bendable Track

AL-76800

Installation Instructions

